

<u>Roco:</u>		
36023	Dampflokomotive 44 1225, DR	TT
42513	Gerade G¼	H0
42651	Böschungsende 6 St.	H0
51292	Digital z21®start Set: Diesellokomotive BR 132 mit Rübenzug, DR	H0
73692	Diesellokomotive Serie 319, RENFE	H0
73693	Diesellokomotive Serie 319, RENFE, DC Sound	H0
73820	Diesellokomotive BR 221, DB	H0
73920	Elektrolokomotive Re 475, BLS Cargo, DC Sound	H0
73930	Elektrolokomotive BR 193, PKP Cargo, DC Sound	H0
73931	Elektrolokomotive BR 383, CD Cargo	H0
76621	Containertragwagen, DB AG	H0
76839	Autotransportwagen Skandiatransport, SJ	H0
79693	Diesellokomotive Serie 319, RENFE, AC Sound	H0
79920	Elektrolokomotive Re 475, BLS Cargo, AC Sound	H0
79932	Elektrolokomotive BR 383, CD Cargo, AC Sound	H0
<u>Fleischmann:</u>		
390075	Elektrische Lokomotive 169 005-6, DB, AC Sound	H0
631781	Digitales Startset: Diesellokomotive BR 212 mit Güterzug, DB	H0
714302	Dampflokomotive BR 37 (37 1009-2), DR	N
714382	Dampflokomotive BR 37 (37 1009-2), DR DCC	N
733807	Elektrolokomotive BR 110, DB	N
733877	Elektrolokomotive BR 110.3, DB Sound	N
734010	Elektrolokomotive Re 4/4", SBB	N
734090	Elektrolokomotive Re 4/4", SBB Sound	N